





Xlayer Selfie Stick with Powerbank 2600mAh and External Remote Shutter Operation Guide




V.05/15

Congratulations on purchasing XLayer Selfie Stick with External Remote Shutter, It is a great accessory for a smart phone, and supports both iPhone and Android phones. We suggest you reading this operation guide to know your Wireless Mini Speaker better, and keep it for future reference.


Fix your phone.



Step 1. Loosen the screen and unfold the phone holder from the stick.



Step 2. Pull up the clip and fix your phone in the holder.



Step 3. Stretch the selfie stick

Connect the external shutter and your phone




1. Remove the battery power breaker sheet from the battery cabinet.
2. Turn on the shutter by moving the switch to "ON".
3. Turn on the Bluetooth function on your phone, search "kjstar" in the device list.
4. Tap the device to connect it, no pin is required.
5. Tap the camera app, now you can take photo by remote shutter.




The Powerbank in the box

Bonus! We include one free powerbank in the box, through which you can fully charge your smart phone 1 time.



Charge the powerbank



We recommend charging the powerbank 100% before every use. To charge the powerbank, connect the Micro USB connector into the powerbank input port, and the other end to a USB charger or a port on laptop or desktop PC.



Charge your smart phone or tablet PC by Powerbank



The powerbank can charge almost all USB-charged device, connect the USB connector to the powerbank output port, and the Micro USB connector to your device.

Specifications:

Selfie Stick

- Length: 21-108 cm
- Max Load: 500 g
- Main Material: Steel
- Weight: 125 g

Remote Shutter

- Bluetooth Version: BT 3.0
- Power: 3V button cell up to 5 m
- Working Scope: 4.5 x 3.3 x 1.0 cm
- Measurement: 8.1 g

Powerbank

- Battery Type: Lithium-Ion Battery
- Capacity: 2600 mAh
- Input: 5V/1A
- Output: 5V/1A
- Main Material: Plastic
- Measurement: 2.2 x 2.5 x 9.7 cm
- Weight: 68.8 g



Safety Notice:

- Fully charge the Powerbank once before first use.
- Use the included cable to charge the Powerbank.
- In order to ensure the durability of the battery during irregular use, charge and discharge the Powerbank once every three months.
- Charging by unsupervised, short circuit or mechanical damage would cause overheating and fire.
- Do not expose the unit to direct sunlight (eg in the car, windowsill)
- Do not immerse the product in water or other liquids.
- Handle the product carefully. Shocks, vibrations or fall from a low height can damage the product.
- If liquid is leaking, stop using the device.
- A remodeling or modification of the product would affect the safety.
- Risk of injury!
- Don't open the appliance without proper authorization and don't perform repairs yourself!
- Please keep the product away from children.
- Modifications and mistakes reserved.




This Electrical device does not belong in the garbage. For proper disposal, please contact the public collection in your community.

Gaudio Multimedia GmbH
Inselkammerstr. 10
82008 Unterhaching
Germany
Made in China




Xlayer Selfie-Stick plus Powerbank 2600mAh und Bluetooth Auslöser Handbuch



V.05/15

Herzlichen Glückwunsch zum Kauf Ihres neuen XLayer Produktes. Wir empfehlen Ihnen, dieses Handbuch vor dem Gebrauch sorgfältig zu lesen und es aufzubewahren.

Befestigung des Smartphones



Step 1: Lösen Sie die Schraube und richten Sie die Halterung auf.



Step 2: Ziehen Sie die Halterungsklammer auseinander, so dass Sie Ihr Smartphone einsetzen können.



Step 3: Ziehen Sie die Selbststange aus.

Verbinden Sie die Fernbedienung mit Ihrem Smartphone




1. Entfernen Sie die kleine Scheibe auf der Rückseite, so dass der Kontakt zur Batterie hergestellt wird.
2. Schalten Sie die Fernbedienung an, indem Sie den Schalter von OFF zu ON schieben.
3. Aktivieren Sie die Bluetooth Funktion Ihres Smartphones und suchen Sie nach "Kjstar".
4. Wählen Sie diesen aus, es ist kein PIN erforderlich.
5. Öffnen Sie die Kamera App auf Ihrem Smartphone um Selfies schießen zu können.




Powerbank

Dieses Set beinhaltet neben einem Selfie Stick plus Fernbedienung auch eine Powerbank, mit der Sie Ihr Smartphone wieder aufladen können.



Aufladen der Powerbank



Wir empfehlen, die Powerbank jedes mal vollständig aufzuladen. Nutzen Sie dazu das mico USB zu USB Kabel an Ihrem USB Anschluss/USB Ladegerät.



Laden Sie ihr Endgerät mit der Powerbank



Die Powerbank lädt so gut wie alle gängigen Geräte, die per USB geladen werden können. Nutzen Sie hierfür entweder das microUSB auf USB Kabel, oder aber Ihr Original USB-Ladekabel Ihres Gerätes.

Spezifikationen:

Selfie Stick

- Länge 21-108 cm
- Max. Belastung 500 g
- Material Metall
- Gewicht 125 g

Remote Shutter

- Bluetooth Version BT 3.0
- Batterie 3V button cell bis zu 5m
- Reichweite 4.5 x 3.3 x 1.0 cm
- Maße 8.1 g
- Gewicht

Powerbank

- Batterietyp Lithium Ionen Batterie
- Kapazität 2600 mAh
- Input 5V/1A
- Output 5V/1A
- Material Kunststoff
- Maße 2.2 x 2.5 x 9.7 cm
- Gewicht 68.8 g



Sicherheitschinnweise Powerbank:

- Vor dem ersten Gebrauch die Powerbank einmal vollständig laden.
- Um die Haltbarkeit des Akkus bei unregelmäßigem Gebrauch zu gewährleisten, laden und entladen Sie das Gerät einmal alle drei Monate.
- Führen Sie den Ladevorgang nicht unbeaufsichtigt durch. Bei Kurzschluss oder mechanischer Beschädigung besteht Überhitzungs- und Brandgefahr.
- Setzen Sie das Gerät nicht direkter Sonneneinstrahlung aus (z.B. im PKW, Fensterbank)
- Tauchen Sie das Produkt niemals in Wasser oder andere Flüssigkeiten
- Behandeln Sie das Produkt sorgfältig. Schläge, Erschütterungen oder Fall aus bereits geringer Höhe können das Produkt beschädigen.
- Bei Austritt von Flüssigkeit, verwenden Sie das Gerät auf keinen Fall weiter.
- Ein Umbauen oder Verändern des Produktes beeinträchtigt die Produktsicherheit. Achtung Verletzungsgefahr!
- Öffnen Sie das Gerät niemals eigenmächtig. Führen Sie Reparaturen nie selbst aus!
- Bitte halten Sie das Gerät von Kindern fern
- Technische Änderungen und Irrtümer vorbehalten.

Hiermit erklärt Gaudio, dass sich das Gerät Xlayer Selfie-Stick & Fun-Bundle in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet. Die Konformitätsklärung kann unter folgender Adresse gefunden werden: www.gaudio.de/faq/2001182-83-84-85.pdf



Gaudio Multimedia GmbH
Inselkammerstr. 10
82008 Unterhaching
Germany
Made in China